


CONFERENCE ROOM, ONE-BUTTON, PRESENTATION SCENE ACTIVATION



CONFERENCE ROOM KIT: PRESS TOP OF ROCKER AND WINDOW SHADES GO DOWN, LIGHTS TURN OFF.  
 PRESS BOTTOM OF ROCKER AND WINDOW SHADES GO UP, LIGHTS TURN ON.  
 USE THE PROJECTOR'S OWN REMOTE TO TURN IT ON/OFF